

QUICK START GUIDE




TUNE750BTNC



WHAT'S IN THE BOX



POWER ON & CONNECT



POWER ON AND
AUTOMATICALLY ENTER PAIRING MODE

CHOOSE "JBL TUNE750BTNC" TO CONNECT

MANUAL PAIRING





POWER OFF

MANUAL PAIRING MODE

CHOOSE "JBL TUNE750BTNC" TO CONNECT

BUTTON COMMAND




>2s




>2s

WIRED LISTENING




MULTI-POINT CONNECTION




ENTER PAIRING MODE WITH THE 2ND DEVICE

- 1 TO SWITCH MUSIC SOURCE, PAUSE THE MUSIC ON THE CURRENT DEVICE AND SELECT PLAY ON THE 2ND DEVICE.
- 2 PHONE CALL WILL ALWAYS TAKE PRIORITY.
- 3 IF ONE DEVICE GOES OUT OF BLUETOOTH RANGE OR POWERS OFF, YOU MAY NEED TO MANUALLY RECONNECT THE REMAINING DEVICE.
- 4 SELECT "FORGET THIS DEVICE" ON YOUR BLUETOOTH DEVICES TO DISCONNECT MULTI-POINT.




1ST BLUETOOTH DEVICE

CHOOSE "JBL TUNE750BTNC" TO CONNECT



2ND BLUETOOTH DEVICE

CHARGING



CHARGE 2HR

LED BEHAVIORS

